

Digoo DC-K3

3D LED Wall Clock

Function Key

MODE/UP/DOWN

POWER: 5V

Cell battery is back up for time setting

Function

Time

Alarm (AL)

Snooze (5-60minutes)

Night mode (Default: 18:00~6:00)

3 levels of brightness (high-medium-low)



Time Setting

1. Press and hold “**MODE**” for two seconds to enter into time mode setting;

The digits are flashing as the below sequence: hour → minute.

2. Press “**UP**” or “**DOWN**” to adjust the value.

3. Under the time mode, press and hold “**UP**” for two seconds to switch the time between 12/24h.

For the 12h mode, the “**PM**” icon will show in the afternoon.

Note: It has no “**AL**” icon under the time setting mode, even the alarm is on.

Alarm Setting

1. Press “**MODE**” and the “**AL**” icon will flash.

2. press and hold “**MODE**” again for three seconds to enter into alarm mode.

The digits are flashing as the below sequence: hour → minute → snooze time setting.

3. Press “**UP**” or “**DOWN**” to adjust the value. The snooze time is limited from 5 to 60 minutes.

When the alarm beeps, press “**MODE**” button, the snooze function will be on and the “**AL**” icon will flash.

When the alarm beeps, press “**UP**” or “**DOWN**” to turn off the alarm. The “**AL**” icon will disappear.

Under the time mode, press the “**DOWN**” to turn on/off the alarm. When the alarm with snooze function is on, the “**AL**” icon will be bright. The alarm will last for 2 minutes if without any operation.

Night Mode Setting

The clock dims for the night mode.

1. Press “**MODE**” button and the AL icon will flash.

2. press “**MODE**” again, later press “**UP**” or “**DOWN**” to turn on/off the night mode.

3. when it displays “**ON**”, press and hold “**MODE**” for two seconds to set the night mode time.

The night mode time is flashing as the below sequence: start hour → start minute → end hour → end minute.

Note: When setting the night mode starting time, the light above will be on. For ending time, the light below will be on.

Brightness Setting

There are 3 levels of brightness. The default brightness is medium.

Under the time mode, press “**UP**” to choose the brightness levels.